



ATTACHMENT
LIKE THIS

SCREWS

NYLOCK BOLTS

FRONT

ATTACH SIDE BRACKETS USING NYLOCK BOLTS



BACK

FRONT



BACK

UNDERSIDE OF REAR FENDER USING SELF TAPPING SCREWS